

Weather station Value line 15010

Overview

For the calculation of the PR (Performance Ratio) the Irradiation (W/m^2), the ambient temperature and the Module surface temperature are needed.

Interfaces

- Lonworks (field devices)
- O&M Handheld Terminal
- 24 V DC Aux. supply

Functionality

- Irradiation (silizium) sensor
- Module surface Temperature
- Ambient Temperature sensor
- I/O Module (Lonworks) for connection to Control room or Inverter room



Rev 2.1 : 06/12 : subject to changes

